



# REST STOP™

Chemicals  
Equipment  
Programs  
Process



## \*Virucidal • Ready-To-Use Germicide • Cleaner • Disinfectant • Deodorant

This ready-to-use, acid free restroom cleaner is an excellent multi-purpose germicidal detergent that disinfects, cleans and deodorizes in one easy step. Formulated with a combination of builders, this product offers excellent cleaning performance on a wide variety of restroom environmental surfaces. Providing outstanding value and economy, its floral fragrance is long lasting for superior odor control.

### Uses

- Toilets
- Urinals
- Sinks
- Counters
- Floors
- Showers
- Glazed ceramic tiles
- Walls

### Benefits

- Kills Streptococcus pyogenes, Salmonella choleraesuis, Pseudomonas aeruginosa and Staphylococcus aureus. \*Virucidal against Influenza Type A, Herpes Simplex Type 2, and HIV-1 (Aids Virus).
- Disinfects, deodorizes and cleans in one single labor-saving step.
- Versatile – Cleans soap scum and a variety of soils from bath and other hard surfaces. Use in areas where odors are a problem.
- Ready-to-use formula provides superior convenience and productivity.

### Properties

Color.....	Clear blue
Detergency.....	Excellent
Film residue.....	Free rinsing
Fragrance.....	Floral, fresh scent
Freeze/thaw.....	3 cycles
pH.....	11 - 12
Shelf life.....	1 year
Viscosity.....	Free flowing
<b>ACTIVE INGREDIENTS:</b>	
n-alkyl (C <sub>14</sub> 60%, C <sub>16</sub> 30%, C <sub>12</sub> 5%, C <sub>18</sub> 5%)	
dimethyl benzyl ammonium chloride.....	0.09%
n-alkyl (C <sub>12</sub> 50%, C <sub>14</sub> 30%, C <sub>16</sub> 17%, C <sub>18</sub> 3%)	
dimethyl ethylbenzyl ammonium chloride.....	0.09%
OTHER INGREDIENTS.....	99.82%
TOTAL.....	100.00%

### Acceptance

Registered with the U.S. Environmental Protection Agency.  
EPA REG. NO. 47371-97-4170

Authorized Betco Distributor



### Directions For Use

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

**DISINFECTION\*/VIRUCIDAL/FUNGICIDAL DIRECTIONS/MOLD AND MILDEW DIRECTIONS:** If surfaces are visibly dirty preclean first. Apply this product with a mop, sponge, cloth, or sprayer on hard, nonporous surfaces to thoroughly wet surfaces. For sprayer applications use a coarse spray device. Spray 6 - 8 inches from surface. Avoid breathing spray. Rub with a brush, sponge, or cloth. Treated surfaces must remain wet for 10 minutes. Wipe dry with a clean cloth, or sponge or allow to air dry. Rinsing is not necessary on floor surfaces that are to be waxed or polished.

For mold and mildew control, repeat application weekly or when growth reappears. Rinse all surfaces that come in contact with food such as countertops, appliances, tables, and stovetops with potable water before reuse. This product should not be used to clean utensils, glassware, and dishes.

This product is not for use on medical device surfaces.

**TO CLEAN AND/OR DEODORIZE:** Apply by mop, sponge, cloth, or spray on hard, nonporous surfaces. Wipe dry with a clean cloth, or sponge, or allow to air dry. **TO CLEAN AND DISINFECT TOILET BOWLS AND URINALS:** Remove gross filth from bowl. Remove or expel over the inner trap residual bowl water. Use four (4) ounces of product in toilet bowl or urinal. Apply (squeeze) directly around bowl and under rim; then brush or swab thoroughly. Allow product to remain on surface for a contact time of 10 minutes; then flush toilet. This product when used as directed will not harm white or colored bowls or inanimate, hard surfaces. Close cap on container after use. **FOR USE ON FINISHED FLOORS:** Apply with a damp mop or autoscrubber. Allow surface to remain wet for 10 minutes. Wipe or allow to air dry.

**KILLS HIV-1 (AIDS Virus) ON PRECLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS** in health care settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids, and in which the surface/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS).

**SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 (AIDS VIRUS) OF SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS. PERSONAL PROTECTION:** Disposable protective gloves, gowns, face masks, or eye coverings as appropriate, must be worn during all cleaning of body fluids, blood, and decontamination procedures. **CLEANING PROCEDURES:** Blood and body fluids must be thoroughly cleaned from surfaces and objects before application of disinfectant.

**CONTACT TIME:** Effective against HIV-1 (AIDS Virus) on hard, nonporous surfaces in the presence of a moderate amount of organic soil (5% blood serum) (providing 1800 ppm of active quaternary) for a contact time of five minutes at room temperature (20 - 25° C). Use a ten minute contact time for disinfection against all other bacteria, fungi, and viruses claimed. **DISPOSAL OF INFECTIOUS MATERIALS:** Blood and other body fluids should be autoclaved and disposed of according to Federal, State, and Local regulations for infectious waste disposal.

### Available In

Case/12 Quarts (946 mL): Item #07012-00  
Case/4 - 1 Gallon (3.78 L): Item #07004-00  
Case/5 Gallon (18.9 L): Item #07005-00  
Drum/55 Gallon (208 L): Item #07055-00

### Safety

Keep out of reach of children. **CAUTION:** Harmful if absorbed through the skin. Avoid contact with skin, eyes or clothing. Wash thoroughly with soap and water after handling. **FIRST AID: IF ON SKIN OR CLOTHING:** Take off contaminated clothing. Rinse skin immediately with plenty of water for 15 - 20 minutes. Call a poison control center or doctor for treatment advice. Have the product container with you when calling a poison control center of doctor or going for treatment.

Literature Item #07092-92

C5010 - Restroom - Acid Free Cleaner

04.07

**BETCO®**